

# modern gardener

## Items enclosed

- 2 x Anchor bolt, nut, washer and threaded bolt
- 2 x Spacer
- 1 x Wire with an Integrated Eye on one end and a Turnbuckle on the other
- 2 x Dome Nuts

## Tools you will need

- 13mm spanner
- 14mm drill bit
- Electric drill
- Spirit level
- Pliers or mould grips

## Instructions

1. Mark the spot that you want to place one end of the wire
2. Using a 14mm drill bit, drill a hole approximately 6.5cm deep ensuring that you drill horizontally
3. Place the anchor bolt end of the threaded bolt into the hole ensuring that there is about 1cm of the threaded bolt extending at the end
4. Holding the threaded bolt, tighten the nut with a 13mm spanner until it is fully tightened and the anchor bolt is secured into the wall.
5. Now loosen the nut and remove it and the washer from the threaded bolt
6. Place the Spacer over the threaded bolt
7. Place the Integrated Eye on the wire over the Spacer and screw the dome nut over the top. If necessary screw or unscrew the threaded bolt into or out of the anchor bolt so that the dome nut can be properly tightened over the Integrated Eye.
8. Place the spirit level along the wire, pull the wire tight and, ensuring the spirit level is exactly horizontal, mark the spot through the eye on the Turnbuckle, where you wish to attach the other end.
9. Repeat steps 2 -5 above
10. Place the eye of the Turnbuckle over the threaded bolt.
11. Using a 13mm spanner, screw the Turnbuckle clockwise until the wire is tight.